
SERVICE

TV-S2011 U



SERVICE MANUAL

COLOR TELEVISION

• This Service Manual contains information about the difference between TV-S2011 (U5AL) and TV-S2011 (U). If requiring other information, see Service Manual of TV-S2011 (U), (S/M Code No. 09-99C-416-8R2).

SUPPLEMENT

DATA

S/M Code No. 09-011-416-8S3

SPECIFICATIONS

Tuner System	Frequency synthesized tuner
TV System	NTSC-M
Channel Coverage	VHF: 2 to 13 UHF: 14 to 69 CATV: 5A, A-1 to A-5, A to W, W+1 to W+84
Program Memory	181
Antenna Input	75 ohms, unbalanced
Picture Tube	20"
Screen Size	406 (W) X 305 (H) mm (16 x 12 1/8 in.) 508 mm (diagonal) (20 in.)
Video Input	1 Vp-p 75 ohms
Audio Input	0.5 Vrms., 33 k ohms more
Speaker	103 X 45 mm (4 1/8 X 1 13/16 in.)
Operating Voltage	120 V AC, 60 Hz
Power Consumption	85 W
Phones Jack	Stereo-mini jack
Operating Temperature	5°C – 40°C
Operating Humidity	35% – 80%
Dimensions	580 (W) X425 (H) X 491 (D) mm (22 7/8 x 16 3/4 x 19 3/8 in.)
Weight	22 kg (48.4 lbs.)

• Design and specifications are subject to change without notice.

ACCESSORIES / PACKAGE LIST

REF. NO.	PART NO.	KANRI NO.	DESCRIPTION
2	8Z-JBE-910-210		IB,U(ESF) S2011/1311 -NEW

To make the best use of this equipment, make sure to obey the following items when repairing (or mending).

1. Do not damage or melt the tunicate of the leading wire on the AC1 side, including the power supply cord.
2. Do not soil or stain the letters on the spec. inscription plates, notice labels, fuse labels, etc.
3. When repairing the part extracted from the conducted side of the board pattern, fix it firmly with applying bond to the pattern and the part.
4. Restore the following items after repairing.
   1) Conditions of soldering of the wires (especially, the distance on the AC1 side).
   2) Conditions of wiring, bundling of wires, etc.
   3) Types of the wries.
   4) Attachment conditions of all types of the insulation.
5. After repairing, always measure the insulation resistance and perform the voltage-withstand test (See Fig-1).

1) The insulation resistance must be 1.5 to 3.0 MΩ when applying 500V per second.
2) In the voltage withstand test, apply 1 KV for 1 minute and check that the GO lamp lights.

* Breaking current set to 10 mA.
* Connect the safety checker as shown in Fig-1, then measure the resistance and perform the test.
* Do not touch the equipment during testing.
* For details of the safety checker, refer to the supplied Operation manual.

Insulation resistance: 1.5 to 3.0 MΩ (500 V/s) Voltage-withstand: 1 KV for 1 minute




Fig-1

When servicing and checking on the TV, note the followings.

1. Keep the notices.
   As for the places which need special attentions, they are indicated with labels or seals on the cabinet, chassis and parts. Make sure to keep the indications and notices in the operation manual.
2. Avoid an electric shock.
   There is a high voltage part inside. Avoid an electric shock while the electric current is flowing.
3. Use the designated parts.
   The parts in this equipment have the specific characteristics of incombustibility and withstand voltage for safety.
   Therefore, use a part which has the same character as the replaced part. Especially as to the important parts for safety which is indicated in the circuit diagram or the table of parts with a ⚠ mark, the designated parts must be used.
4. Put parts and wires in the original position after assembling or wiring.
   There are parts which use the insulation material such as a tube or tape for safety, or which are assembled so that these parts do not make contact with the printed board. The inside wiring is designed not to get close to the pyrogenic parts and high voltage parts. Therefore, put these parts in the original positions.
5. Take care of the cathode-ray tube.
   By setting an explosion-proof cathode-ray tube in this equipment, safety is secured against implosion. However, when removing it or servicing from the back, it gives out shock that is dangerous. Take enough care to deal with it.
6. Avoid an X-ray.
   Safety is secured against an X-ray by giving considerations to the cathode-ray tube and the high voltage peripheral circuit, etc. Therefore, when repairing the high voltage peripheral circuit, use the designated parts and do not change the circuit. Repairing, except indicates, causes rising of high voltage, and the cathode-ray tube emits an X-ray.
7. Perform a safety check after servicing.
   Confirm that the screws, parts and wiring which were removed in order to service are put in the original positions, or whether there are deteriorated portions around the places serviced.

⚠ Safety Components Symbol

This symbol is given to important parts which serve to maintain the safety of the product, and which are made to confirm to special Safety Specifications.
Therefore, when replacing a component with this symbol make absolutely sure that you use a designated part.

ELECTRICAL MAIN PARTS LIST

IC

REF. NO.	PART NO.	KANRI NO.	DESCRIPTION
	8Z-JBH-622-010		IC,M37272M8-183SP
	87-A91-538-010		RCR UNIT,SBX1981-72P
	87-A21-133-080		IC,BMR-0101D
	87-A21-788-010		IC,KIA7809API
	87-A21-239-010		IC,TA1201CN
	87-A21-378-010		IC,S-24C04BDP-1A
	87-002-421-010		IC,NJM2233BL
	87-A21-090-010		IC,LA4600
	87-027-666-010		IC,TC4052BP
	87-070-237-010		IC,LA7832
	8Z-JBH-605-010		IC,CXA2104S
	87-A21-290-010		IC,STR30110

TRANSISTOR

REF. NO.	PART NO.	KANRI NO.	DESCRIPTION
	87-026-269-080		TR,DTA114ES
	89-327-854-080		TR,2SC2785F
	89-111-755-080		TR,2SA1175F
	89-110-154-080		TR,2SA1015Y
	87-026-245-080		TR,DTC114ES
	87-A30-176-010		TR,2SC1573A P/Q/R
	89-320-012-080		TR,2SC2001L
	87-A30-050-010		TR,2SD2499

DIODE

REF. NO.	PART NO.	KANRI NO.	DESCRIPTION
	87-017-931-080		ZENER,MTZJ5.6B
	87-002-743-080		ZENER,MTZJ 33B
	87-070-136-080		ZENER,MTZJ5.1B
	87-A40-523-080		ZENER,MTZJ9.1B
	87-A40-348-080		ZENER,MTZJ3.3A
	87-A40-611-080		ZENER,MTZJ3.9B
	87-020-465-080		DIODE,1SS133
	87-A40-520-080		ZENER,MTZJ11B
	87-A40-286-080		DIODE,RGP10JE-5025
	87-070-274-080		DIODE,1N4003 SEM
	87-A40-824-090		DIODE,RU3LFB1
	87-A40-328-010		DIODE,GBU4JL

MAIN C.B


REF. NO.	PART NO.	KANRI NO.	DESCRIPTION
BT301	87-JBC-625-010		CONN ASSY,5P V WHT TV-NK
BT601	87-JBG-626-010		CONN ASSY,4P V WHT TV-NK
C1	87-A12-091-080		CAP,E 10-50 SMG
C2	87-018-134-080		CAPACITOR,TC-U 0.01-16
C3	87-018-134-080		CAPACITOR,TC-U 0.01-16
C4	87-018-196-080		CAP, CER 1500P-16V
C5	87-A12-087-080		CAP,E 1-50 SMG
C7	87-A12-063-080		CAP,E 220-10 SMG
C15	87-018-123-080		CAP, CER 220P-50V
C16	87-A12-087-080		CAP,E 1-50 SMG
C17	87-018-131-080		CAP, CER 1000P-50V
C18	87-018-128-080		CAP, CERA-SOL SS 560P
C19	87-A12-083-080		CAP,E 0.1-50 SMG
C23	87-018-123-080		CAP, CER 220P-50V
C24	87-018-131-080		CAP, CER 1000P-50V
C101	87-A12-090-080		CAP,E 4.7-50 SMG
C104	87-A12-063-080		CAP,E 220-10 SMG
C201	87-018-134-080		CAPACITOR,TC-U 0.01-16
C202	87-018-134-080		CAPACITOR,TC-U 0.01-16
C203	87-A12-086-080		CAP,E 0.47-50 SMG
C204	87-018-134-080		CAPACITOR,TC-U 0.01-16
C205	87-A12-068-080		CAP,E 470-16 SMG
C206	87-A10-287-080		CAP,M 2200P-50 J
C207	87-A12-086-080		CAP,E 0.47-50 SMG
C208	87-018-134-080		CAPACITOR,TC-U 0.01-16
C209	87-A12-066-080		CAP,E 47-16 SMG
C210	87-018-115-080		CAP, CER 47P-50V
C211	87-018-115-080		CAP, CER 47P-50V
C214	87-A12-086-080		CAP,E 0.47-50 SMG
C215	87-A12-086-080		CAP,E 0.47-50 SMG
C301	87-A12-091-080		CAP,E 10-50 SMG
C302	87-A12-091-080		CAP,E 10-50 SMG
C303	87-A12-091-080		CAP,E 10-50 SMG
⚠ C304	87-A12-091-080		CAP,E 10-50 SMG
C305	87-018-134-080		CAPACITOR,TC-U 0.01-16
C306	87-A12-061-080		CAP,E 47-10 SMG
C307	87-A10-299-080		CAP,M 0.022-50 J
C308	87-A12-086-080		CAP,E 0.47-50 SMG
C309	87-018-147-080		CAP,TC-U 10P-50 CH
C310	87-018-119-080		CAP, CER 100P-50V
C311	87-A11-148-080		CAP, TC U 0.1-50 ZF
C312	87-A11-148-080		CAP, TC U 0.1-50 ZF
C313	87-A11-148-080		CAP, TC U 0.1-50 ZF
C314	87-018-134-080		CAPACITOR,TC-U 0.01-16
C315	87-018-131-080		CAP, CER 1000P-50V
C316	87-A10-378-080		CAP,E 2.2-50 K SH
C317	87-A12-088-080		CAP,E 2.2-50 SMG
C318	87-018-134-080		CAPACITOR,TC-U 0.01-16
C319	87-016-251-080		CAP,E 220-16 M SMG
C320	87-018-196-080		CAP, CER 1500P-16V
C321	87-A12-090-080		CAP,E 4.7-50 SMG
C323	87-010-379-080		CAP,E 22-16 M 11L SME
C324	87-A12-086-080		CAP,E 0.47-50 SMG
C325	87-A12-086-080		CAP,E 0.47-50 SMG
C328	87-A12-091-080		CAP,E 10-50 SMG
C330	87-A12-087-080		CAP,E 1-50 SMG
C332	87-018-134-080		CAPACITOR,TC-U 0.01-16
C334	87-018-134-080		CAPACITOR,TC-U 0.01-16
C335	87-A10-918-080		CAP,E 100-16 SMG
C336	87-A11-148-080		CAP, TC U 0.1-50 ZF
C338	87-A12-086-080		CAP,E 0.47-50 SMG
C341	88-707-959-810		CAP,M 0.39-50 J TF
C342	87-A12-087-080		CAP,E 1-50 SMG
C343	87-018-131-080		CAP, CER 1000P-50V
C401	87-A12-068-080		CAP,E 470-16 SMG
C402	87-A12-068-080		CAP,E 470-16 SMG
C403	87-A12-068-080		CAP,E 470-16 SMG
C404	87-A10-918-080		CAP,E 100-16 SMG
C405	87-A12-090-080		CAP,E 4.7-50 SMG
C406	87-A12-084-080		CAP,E 0.22-50 SMG
C407	87-A12-084-080		CAP,E 0.22-50 SMG
C410	87-A12-091-080		CAP,E 10-50 SMG
C411	87-A12-091-080		CAP,E 10-50 SMG
C412	87-A12-091-080		CAP,E 10-50 SMG
C413	87-A12-091-080		CAP,E 10-50 SMG
C414	87-A12-091-080		CAP,E 10-50 SMG
C501	87-A12-373-080		CAP,M 0.056-100 J CP
C502	87-A10-831-080		CAP,E 1000-25 M SMG
C503	87-A12-087-080		CAP,E 1-50 SMG
C504	87-A12-087-080		CAP,E 1-50 SMG
C508	87-A10-469-080		CAP,CER 2200P-500 K B DD10
C510	87-018-131-080		CAP, CER 1000P-50V
C511	87-A12-079-080		CAP,E 100-35 SMG
C512	87-018-127-080		CAP, CER 470P-50V
C601	87-016-373-080		CAP,E 10-250 M SME
⚠ C603	87-010-974-080		CAP,CER 220P-500 B
C604	87-010-396-080		CAP,E 470-35 SME
C605	87-A10-831-080		CAP,E 1000-25 M SMG
C606	8Z-JBH-626-010		CAP,M/P 0.30-250 J A TYPE
C607	87-A11-321-090		CAP,E 100-160 M 105 YXA
C608	8Z-JBJ-602-010		CAP,CER 220P-2K K BN
⚠ C609	87-016-482-010		CAP,PP 6800P-1.6K J DKR
⚠ C610	87-010-974-080		CAP,CER 220P-500 B
⚠ C611	87-010-974-080		CAP,CER 220P-500 B
C612	87-A12-091-080		CAP,E 10-50 SMG
C613	87-A12-088-080		CAP,E 2.2-50 SMG
C617	87-016-215-080		CAP,E 1-160 M TWSS

	REF. NO.	PART NO.	KANRI NO.	DESCRIPTION
⚠	C620	88-130-102-080		RES,1K-1/4W J
	C703	87-015-464-080		CAP,E 4.7-16 BP
	C704	87-A10-292-080		CAP,M 5600P-50 J
	C705	87-A10-296-080		CAP,M 0.012-50 J
	C706	87-A12-087-080		CAP,E 1-50 SMG
	C707	87-A12-090-080		CAP,E 4.7-50 SMG
	C708	87-A12-091-080		CAP,E 10-50 SMG
	C709	87-A12-090-080		CAP,E 4.7-50 SMG
	C710	87-A10-918-080		CAP,E 100-16 SMG
	C711	87-015-464-080		CAP,E 4.7-16 BP
	C712	87-A12-090-080		CAP,E 4.7-50 SMG
	C713	87-015-464-080		CAP,E 4.7-16 BP
	C714	87-A10-288-080		CAP,M 2700P-50 J
	C716	87-016-301-080		CAP,TN 3.3-16K DN
	C717	87-015-464-080		CAP,E 4.7-16 BP
	C718	87-016-302-080		CAP,TN 10-16K DN
	C719	87-A12-087-080		CAP,E 1-50 SMG
⚠	C801	87-A10-374-010		CAP,M/P 0.1-275 K RMR
⚠	C804	87-A10-374-010		CAP,M/P 0.1-275 K RMR
	C807	87-A10-831-090		CAP,E 1000-25 M SMG
	C808	87-A12-071-080		CAP,E 47-25 SMG
	C809	87-A11-148-080		CAP, TC U 0.1-50 ZF
	C810	87-010-405-080		CAP,E 10-50 M 11L SME
	C811	87-A10-867-090		CAP,CER 2200P-2K K R
	C812	87-A10-867-090		CAP,CER 2200P-2K K R
	C813	8Z-JBE-604-090		CAP,E 560U-200K
	C815	87-A11-319-080		CAP,E 22-160 M 105 YXA
⚠	C816	87-012-388-010		CAP,CER 2200P-125M E DE
	C817	87-A11-319-080		CAP,E 22-160 M 105 YXA
	C818	87-A10-831-090		CAP,E 1000-25 M SMG
	CF201	84-LB3-626-010		FLTR,TPS4.5MB2
	CF202	87-008-574-080		FLTR,SFSH4.5MCB
	CN1	87-009-195-010		CONN,5P B5BEH
	CN401	87-049-469-010		CONN,4P V
	CN601	87-A60-933-010		CONN,4P V B04(5-3)B-DVS-L
⚠	CN801	87-099-674-010		CONN,2P VA V
⚠	CN802	82-481-649-010		CONN,2P V TV-50P
	CNA601	8Z-JBH-638-010		CONN ASSY,5P V W 320-600-US
	D1	87-070-110-010		LED,SLP-181B-51 RED
⚠	D820	8Z-JBH-606-010		VRIS,TNR15G271K
⚠	F801	87-035-489-010		FUSE,4A 125V T237
	FB1	8Z-JBH-635-080		COIL,CORE BL01RN1-A62
	FB2	8Z-JBH-635-080		COIL,CORE BL01RN1-A62
	FB3	8Z-JBH-635-080		COIL,CORE BL01RN1-A62
	FB100	8Z-JBH-636-010		F-BEAD,2.7-5.5-4 FSOB060
⚠	FC801	87-A90-160-080		FUSE CLAMP,FC 51F
⚠	FC802	87-A90-160-080		FUSE CLAMP,FC 51F
	FR401	87-029-151-090		RES,FUSE 10-2W J
	FR601	87-A00-063-060		RES,FUSE 2.2-1/2W J R-TYPE
	FR602	87-A00-056-060		RES,FUSE 1.5-2W J R-TYPE
⚠	FR603	87-A00-056-060		RES,FUSE 1.5-2W J R-TYPE
	FR604	87-A00-050-060		RES,FUSE 2.2-1W J R-TYPE
⚠	FR605	87-A00-650-090		RES FUSE,2.2K 1W J RF1S
	HL1	84-LB3-216-010		HLDR,LED
	J401	87-A60-322-110		JACK,PIN 3P Y-W-R W/SW
	J402	8Z-JBH-616-010		JACK,PIN 3P Y
	J403	87-A60-420-010		JACK,3.5 ST (MSC)
	JW1	8Z-JBH-635-080		COIL,CORE BL01RN1-A62
	JW16	87-003-147-080		COIL,22UH J LAL02
	JW26	8Z-JBH-635-080		COIL,CORE BL01RN1-A62
	L1	87-003-147-080		COIL, 22UH J LAL02
	L2	87-005-614-080		COIL 100UH LAV35 J
	L201	8Z-JBR-612-010		COIL,SIF 4.5MHZ 504BN
	L203	87-003-148-080		COIL BIAS 33UH
	L204	87-003-282-080		COIL,12UH
	L205	8Z-JBH-610-010		COIL,PIF-SQ57EL349A 45.75MHZ
	L206	87-005-612-080		COIL,68UH J LAV35
	L207	87-003-147-080		COIL, 22UH
⚠	L602	87-A50-040-010		COIL,2.2MH
⚠	L603	8Z-JBE-606-010		COIL,LINEARITYSH5L8409


	REF. NO.	PART NO.	KANRI NO.	DESCRIPTION
⚠	L604	8Z-JBE-608-010		COIL,CHOKEELC08D560E
	L701	87-005-614-080		COIL 100UH LAV35 J
⚠	L801	8Z-JBH-613-010		FLTR,LINE ELF18N016A
	R107	87-A00-331-090		RES,M/F 27K-2W J RSF(S)
	R110	87-A00-160-090		RES,M/F 33-2W J RSF(S)
⚠	R307	87-025-427-080		RES,M/F 27K-1/6W F
⚠	R308	88-121-681-080		RES,680-1/8W J
⚠	R309	87-025-380-080		RES,M/F 15K-1/6W F
	R312	87-A00-356-090		RES,M/F 22-2W J RSS2X
⚠	R601	88-130-154-080		RES,150K-1/4W J
⚠	R602	88-121-223-080		RES,22K-1/8W J
⚠	R603	88-121-473-080		RES,47K-1/8W J
	R606	87-A00-795-050		RES,M/F 0.47-1/2W J
⚠	R607	88-140-332-080		RES,3.3K-1/2W J
⚠	R610	87-A00-548-090		RES,M/F 5.6K-2W J ERGS
⚠	R611	87-A00-548-090		RES,M/F 5.6K-2W J ERGS
⚠	R624	87-A00-654-090		RES,FUSE 150-2W J RF2S
	R706	87-A00-130-080		RES,M/F 62K-1/6W F
⚠	R801	8Z-JBH-629-080		RES,SD 2.2M-1/2W K ERC 12UG
	R809	87-A00-277-090		RES,CEM 2.2-10W J RGC
⚠	R811	8Z-JBE-603-090		RES,CEM 180-20W J ZY
⚠	R816	87-025-425-080		RES,M/F 12K-1/6W F
⚠	RY801	87-A90-358-010		RELAY,12V LK1AF
	SF201	8Z-JBH-633-010		FLTR,SAW M1969-US
	SW1	87-A90-712-080		SW,TACT EVQ11L07K
	SW2	87-A90-712-080		SW,TACT EVQ11L07K
	SW3	87-A90-712-080		SW,TACT EVQ11L07K
	SW4	87-A90-712-080		SW,TACT EVQ11L07K
	SW5	87-A90-712-080		SW,TACT EVQ11L07K
	SW6	87-A90-712-080		SW,TACT EVQ11L07K
	SW7	87-A90-712-080		SW,TACT EVQ11L07K
⚠	T601	8Z-JBE-620-010		FBT,US 21 ST
⚠	T602	85-JT2-653-010		PT,HDT-TV141-2
⚠	T603	8Z-JBH-612-010		FLTR,PULSE ELF15N005A
⚠	T801	8Z-JBH-614-010		PT,US TP8155T
⚠	TH801	87-A90-996-010		POS-THMS,S1481-B50-A10
	TU101	8Z-JBE-610-010		TU UNIT,USA ENV56D74G3
	X1	87-030-212-080		CERA LOCK CST8.0M
	X301	87-A70-007-080		VIB,XTAL 3.58MHZ AQC-1001
	X302	87-030-327-010		VIB,CER CSB503F30


NK C.B

	REF. NO.	PART NO.	KANRI NO.	DESCRIPTION
	C901	87-A10-833-090		CAP,CER 1000P-2K K R
	C902	87-018-126-080		CAP,TC-U 390P-50 B
	C903	87-018-126-080		CAP,TC-U 390P-50 B
	C904	87-018-126-080		CAP,TC-U 390P-50 B
	C907	87-A12-068-080		CAP,E 470-16 SMG
	C908	87-A12-066-080		CAP,E 47-16 SMG
	CN901	87-049-469-010		CONN,4P V
	CN902	87-009-033-010		CONNECTOR, 5P
	CN904	87-A60-485-010		CONN,2P V LV GRA
	L901	87-005-615-080		COIL,120UH J LAV35
	R904	87-A00-165-090		RES,M/F 15K-2W J RSF(S)
	R905	87-A00-165-090		RES,M/F 15K-2W J RSF(S)
	R906	87-A00-165-090		RES,M/F 15K-2W J RSF(S)
	S901	86-LBR-670-010		SOCKET,CRT 9P HPS1521



A MAIN C.B
ANTENNA
TU101
VIDEO
AUDIO L (MONO)
AUDIO R
VIDEO 1 INPUT
(REAR)
J402 (1/3)
J402 (2/3)
J402 (3/3)
INPUT I²C BUS CONNECTOR
CN1
TO B NK C.B CN901
CN601
CNA601
(DY UNIT)
DY
ANODE CAP
CRT TO V901
TO B NK C.B
FOCUS
SCREEN
TO B NK C.B CN902
SP401,402 SPEAKERS
SP401 (LCH)
SP402 (RCH)
BT401
J403
VIDEO 2 INPUT
(FRONT)
J401 (1/3)
J401 (2/3)
J401 (3/3)
TV/VIDEO ENTER
MENU
VOLUME
CHANNEL
(REMOTE SENSOR) IC2
(STANDBY) D1
POWER
AC 120V 60HZ
BT801
CN802
(DEGAUSSING COIL)
IC1
IC301
IC401
IC701
T801
T601

SCHEMATIC DIAGRAM – 1 (MAIN / NK)




B NK C.B
C904
R909
D903
R915
D902
R914
C903
R908
R911
R910
Q903
R902
R903
CN904
C901
R906
R905
TP902
Q902
C907
D904
Q904
D901
R913
C902
R907
Q901
R904
R901
L901
CN902
C908
CN901
S901
TO CRT GND
<RED> FOCUS
<ORG> SCREEN
TO A MAIN C.B
FROM A MAIN C.B
BT301
FROM A MAIN C.B
BT601
V901
CRT

MECHANICAL EXPLODED VIEW 1 / 1



MECHANICAL PARTS LIST 1 / 1

REF. NO.	PART NO.	KANRI NO.	DESCRIPTION
1	87-054-086-010		BADGE,AIWA 52.5
2	8Z-JBE-003-010		PANEL,FR S2011 UL
3	86-LBB-007-010		LENS,LED
4	88-JBJ-009-010		GRILLE,SPKR R ST
5	86-LBU-201-010		HLDR,AC CORD
⚠ 6	8Z-JBH-618-010		AC CORD,US BLK
7	87-A91-412-010		SPKR,F 4*10 8OHM 5W S0410J06
8	8Z-JBE-002-010		CABI,FR UL
9	88-JBJ-008-010		GRILLE,SPKR L ST
⚠ 10	8Z-JBE-611-110		CRT,ASSY:A51JFC82X36(C)
11	84-LB3-205-010		SPR-E,EARTH
12	86-LBN-622-110		CONN ASSY,1P CRT-GND
⚠ 13	8Z-JBE-605-010		DGC,21'US
14	8Z-JBE-007-010		CABI,REAR UL
15	87-A90-332-010		HLDR,SF-2001 HV CABLE
16	8Z-JBE-010-010		PANEL,REAR U MPI
17	8Z-JBW-602-110		CONN ASSY,4P V WHT SP20
18	84-LB3-216-010		HLDR,LED
19	8Z-JBH-201-010		HLDR,FBT ST
A	87-067-680-010		BVI T3+3-10
B	87-067-758-010		BVT2+3-12 W/O SLOT
C	87-067-844-010		BVT2+4-16 BLK
D	86-LBB-206-010		S-SCREW,ASSY TV5-40 W20
E	87-B10-071-010		BVT2+3-16 W/O SLOT B
F	87-067-761-010		TAPPING SCREW, BVT2+3-10
G	87-751-074-410		VT2+2.6-8 W/O CUT
H	87-067-579-010		TAPPING SCREW, BVT2+3-8

COLOR NAME TABLE

Basic color symbol	Color	Basic color symbol	Color	Basic color symbol	Color
B	Black	C	Cream	D	Orange
G	Green	H	Gray	L	Blue
LT	Transparent Blue	N	Gold	P	Pink
R	Red	S	Silver	ST	Titan Silver
T	Brown	V	Violet	W	White
WT	Transparent White	Y	Yellow	YT	Transparent Yellow
LM	Metallic Blue	LL	Light Blue	GT	Transparent Green
LD	Dark Blue	DT	Transparent Orange	GM	Metallic Green
YM	Metallic Yellow	DM	Metallic Orange	PT	Transparent Pink
LA	Aqua Blue	GL	Light Green		

アイワ株式会社 〒110-8710 東京都台東区池之端1-2-11 ☎03(3827)3111 (代表)
AIWA CO.,LTD. 2-11, IKENOHATA 1-CHOME, TAITO-KU, TOKYO 110, JAPAN TEL:03 (3827) 3111

9820543 0251431 Printed in Singapore